

Complete Assy
12"-22"W x 8"-16"H

A1a	Right
A1b	Left

Includes all mounting hardware

Complete Assy
22"-26"W x 8"-16"H

B1a	Right
B1b	Left

Includes all mounting hardware

Complete Assy
26"-32"W x 8"-16"H

C1a	Right
C1b	Left

Includes all mounting hardware

Armrest Only 12"-22"W

D1a	Right
D1b	Left

Does not include M1

Armrest Only 22"-26"W

E1a	Right
E1b	Left

Does not include M1

Armrest Only 26"-32"W

F1a	Right
F1b	Left

Does not include M1

Articulating Linkage

G1a	Right
G1b	Left

The articulating linkages are not width dependent and are used across all armrest assemblies.

Includes I1, J1, K1, & N1.
Does not include H1 or M1

Serviceable Components

The 2 Hole T-nut is included with the complete armrest assy's (A1a - C1b) and the articulating linkages (G1a / G1b). It is not available individually.

Wire Guide Mounting Location

Please note:
Only serviceable parts contain callouts. For all other parts the complete assembly must be selected.